

POLAIRE

POLAIRE JOUBERT FRQNC
585 rue actisère - 38570 Le Cheylas
Tel : 04.76.92.34.64
E-mail : pro@polaire.eu
www.polaire.eu

POLAIRE

Citroen Berlingo	09/18	→
Citroen Berlingo Van	06/18	→
Opel Combo Cargo	09/18	→
Opel Combo Life	01/18	→
Peugeot Partner	09/18	→
Peugeot Rifter Toyota	08/18	→
Proace City	05/20	→
Toyota Proace City Verso	06/19	→
Fiat Doblò	08/22	→
Mercedes Citan	09/21	→
Mercedes Citan Tourer	11/21	→
Mercedes Classe T	06/22	→
Mercedes eCitan	12/23	→
Mercedes EQT	12/23	→
Renault Kangoo Van	06/21	→
Renault Kangoo	06/21	→
Nissan Townstar	12/21	→

KIT 1° e 2° Barra - Versione L1 e L2 **kit. 4 pz.**

ISTRUZIONI DI MONTAGGIO
NOTICE DE MONTAGE
MONTAGEANWEISUNGEN
ASSEMBLY INSTRUCTIONS
INSTRUCCIONES DE MONTAJE
MONTAGE INSTRUCTIES
INSTRUÇÕES PARA A MONTAGEM
WSKAZOWKI MONTAŻA
MONT'ZNI N'VOD
SMER POKONCEN

Art. 17425800



- | 5505606000 | | 17201000 | |
|---|----------------|---|--------------|
|  | |  | M8x75 mm x2 |
|  | 8730 x 4 |  | M8x55 mm x2 |
|  | 4091023000 x 1 |  | Ø8,2x14 x4 |
|  | 4091024000 x 1 |  | Ø8,4x16 x4 |
|  | 4091034000 x 2 |  | Cod. 8600 x4 |
|  | F20869110 x 2 |  | F29240264 x6 |
| | |  | x1 |
| | |  | x1 |
| | |  | 8606 x8 |
| | |  | M8x45 mm x4 |
| | |  | M8 x4 |

